

[Home \(/sg/en/\)](#) / [Drives \(/sg/en/Drives/c/3000\)](#) /  
[Low Voltage Drives \(/sg/en/Drives/Low-Voltage-Drives/c/3301\)](#) /  
[VLT® Midi Drive FC 280 \(/sg/en/Drives/Low-Voltage-Drives/VLT%C2%AE-Midi-Drive-FC-280/c/7559\)](#) / **134U7769**  
› **Export page (/sg/en/Drives/Low-Voltage-Drives/VLT%C2%AE-Midi-Drive-FC-280/FC-280PK55T4E20H2BXCXXXSXXXXAL/p/134U7769/getExport)**



[Larger View](#)

**FC-280PK55T4E20H2BXCXXXSXXXXAL**

# 134U7769

Frequency converter

FC-280PK55T4E20H2BXCXXXSXXXXAL

VLT® Midi Drive FC-280

0.55 kW / 0.75 HP, Three phase 380-480 VAC

IP20 / Chassis, EMC Cat C3 (200/400V)

Brake chopper, No display

Coated PCB, Latest release

Integrated PROFINET

Frame: K1

Other options according to Model code

**Model code:** FC-280PK55T4E20H2BXCXXXSXXXXAL

Note: The FC 280 does not include an LCP display or Memory Module.

The LCP and the Memory Module can be ordered as an Accessory.

Note: Mounting adapter plates for VLT2800 are available as an Accessory.

[Read less](#)

› [View Efficiency Data](#) (<https://ecosmart.mydrive.danfoss.com/#/cdm-report/FC-280PK55T4E20H2/en>)



Where to buy

+ Add to comparison list

+Add to My Product List

Product detailsDocumentsCertificatesVisualsAccessoriesSpare PartsServices

Product details

Gross weight	3.06 kg
Net weight	2.63 kg
Volume	16.53 l
EAN	5710108038212

VLT® Midi Drive FC 280

Product View (Switch)	GLBL	Global (Standard)
Product Group	FC-	VLT® Midi Drive FC-
Series	280	280
Power Size	PK55	0.55 kW / 0.75 HP
Voltage	T4	Three phase 380-480 VAC
Enclosure	E20	IP20 / Chassis
RFI Filter	H2	EMC Cat C3 (200/400V)
Brake & Stop	B	Brake chopper
Display	X	No display
Coating	C	Coated PCB
Mains Option	X	No mains options
Adaptation A	X	No Adaption
Adaptation B	X	No Adaption
Special Version	SXXX	Latest release
Software Language Pack	X	Standard language pack

<b>Control Card</b>	AL	Integrated PROFINET
<b>Frame Size</b>	K1	K1
<b>Typecode Part 1</b>		FC-280PK55T4E20H2BXC
<b>Typecode Part 2</b>		XXXSXXXXAL
<b>Product Catalog</b>	NO_VIEW	NO VIEW
<b>Calculated Gross Weight [kg]</b>		2.8
<b>Calculated Net Weight [kg]</b>		2.5
<b>Intermittent Current (HO) [A]</b>		2.7
<b>Intermittent Current (HO) [A]</b>		2.7
<b>Continuous Current (HO) [A]</b>		1.7
<b>Continuous Current (HO) [A]</b>		1.6
<b>Power Loss HO [W]</b>		25.2
<b>kVA</b>		1.2
<b>Power 160% (HO) [KW]</b>		0.55
<b>Height [mm]</b>		210
<b>Width w/ no C options [mm]</b>		75
<b>Depth [mm]</b>		168
<b>Vendor</b>	ERR01	Cannot Determine Vendor
<b>Recommended Factory</b>	ERR01	Cannot Determine Vendor
<b>Modelcode01</b>		FC-280PK55T4E20H2BXC
<b>Modelcode02</b>		XXXSXXXXAL
<b>ECCN EU</b>		Y901
<b>ECCN US</b>		3A999.a
<b>Recommended Plant</b>		ERR01

## Documents

Documen...	Singapore	English	Title	
<b>Application guide</b>	Singapore	English	<b>Encoder-less Safety using DOLD Module</b> <a href="https://assets.danfoss.com/documents/273085/AB361177609013en-000101.pdf">(/assets.danfoss.com/documents/273085/AB361177609013en-000101.pdf)</a> AB361177609013en-000101 6057 KB	<a href="#">(/as</a>
<b>Brochure</b>	Singapore	English	<b>VLT® Midi Drive FC 280 Selection Guide</b> <a href="https://assets.danfoss.com/documents/316954/AD396854554545en-010201.pdf">(/assets.danfoss.com/documents/316954/AD396854554545en-010201.pdf)</a> AD396854554545en-010201 20648 KB	<a href="#">(/as</a>
<b>Design guide</b>	Singapore	English	<b>DrivePro® Retrofit VLT® 2800 to VLT® Midi Drive FC 280</b> <a href="https://assets.danfoss.com/documents/366700/AJ440051329024en-000102.pdf">(/assets.danfoss.com/documents/366700/AJ440051329024en-000102.pdf)</a> AJ440051329024en-000102 6300 KB	<a href="#">(/a:</a>
<b>Design guide</b>	Singapore	English	<b>VLT® Midi Drive FC 280</b> <a href="https://assets.danfoss.com/documents/272336/AJ275647019268en-000501.pdf">(/assets.danfoss.com/documents/272336/AJ275647019268en-000501.pdf)</a> AJ275647019268en-000501 16912 KB	<a href="#">(/a:</a>
<b>Installation guide</b>	Singapore	English	<b>Blind Cover</b> <a href="https://assets.danfoss.com/documents/276969/AN361179838393en-000201.pdf">(/assets.danfoss.com/documents/276969/AN361179838393en-000201.pdf)</a> AN361179838393en-000201 187 KB	<a href="#">(/as</a>
<b>Installation guide</b>	Singapore	English	<b>Bus Decoupling Kit</b> <a href="https://assets.danfoss.com/documents/276710/AN361179829411en-000101.pdf">(/assets.danfoss.com/documents/276710/AN361179829411en-000101.pdf)</a> AN361179829411en-000101 322 KB	<a href="#">(/as</a>
<b>Installation guide</b>	Singapore	English	<b>Control Cassettes Installation Guide</b> <a href="https://assets.danfoss.com/documents/273279/AN424547088970en-000401.pdf">(/assets.danfoss.com/documents/273279/AN424547088970en-000401.pdf)</a> AN424547088970en-000401 721 KB	<a href="#">(/as</a>
<b>Installation guide</b>	Singapore	English	<b>Fan Replacement</b> <a href="https://assets.danfoss.com/documents/274396/AN446158027410en-000101.pdf">(/assets.danfoss.com/documents/274396/AN446158027410en-000101.pdf)</a> AN446158027410en-000101 293 KB	<a href="#">(/as</a>

			Title	
<b>Installation guide</b>	Singapore	English	<b>Graphical LCP Adapter</b> <a href="http://assets.danfoss.com/documents/276940/AN361179836395en-000201.pdf">http://assets.danfoss.com/documents/276940/AN361179836395en-000201.pdf</a> AN361179836395en-000201 180 KB	(//as
<b>Installation guide</b>	Singapore	English	<b>Memory Module Programmer</b> <a href="http://assets.danfoss.com/documents/277145/AN361179851415en-000101.pdf">http://assets.danfoss.com/documents/277145/AN361179851415en-000101.pdf</a> AN361179851415en-000101 133 KB	(//as

#### View:



10 (/sg/en/setDocumentsPage?  
productCode=134U7769&documentCertificateType=DanfossDocument&page=0&pageSize=10)  
25 (/sg/en/setDocumentsPage?  
productCode=134U7769&documentCertificateType=DanfossDocument&page=0&pageSize=25)  
50 (/sg/en/setDocumentsPage?  
productCode=134U7769&documentCertificateType=DanfossDocument&page=0&pageSize=50)  
⏪ (/sg/en/setDocumentsPage?  
productCode=134U7769&documentCertificateType=DanfossDocument&page=0&pageSize=10)  
1 / 3  
(/sg/en/setDocumentsPage?  
productCode=134U7769&documentCertificateType=DanfossDocument&page=1&pageSize=10)

## Certificates


Document Type	Singapore	English	Title	
<b>EU-UK Declaration</b>	Singapore	English	<b>Danfoss EU-UK 00728753 A14</b> <a href="http://assets.danfoss.com/approvals/208046/ID365934718350-0301.pdf">http://assets.danfoss.com/approvals/208046/ID365934718350-0301.pdf</a> ID365934718350-0301 2341 KB	(//ass
<b>EU-UK Declaration</b>	Singapore	English	<b>Danfoss EU-UK 00738276 A4</b> <a href="http://assets.danfoss.com/approvals/201538/ID383146070796-0201.pdf">http://assets.danfoss.com/approvals/201538/ID383146070796-0201.pdf</a> ID383146070796-0201 2174 KB	(//ass
<b>Fieldbus Certificate</b>	Singapore	English	<b>PROFIBUS Z11394</b> <a href="http://assets.danfoss.com/approvals/196656/ID375733660132-0201.pdf">http://assets.danfoss.com/approvals/196656/ID375733660132-0201.pdf</a> ID375733660132-0201 81 KB	(//ass

			Title	
Fieldbus Certificate	Singapore	English	<b>PROFIBUS Z20309</b> (//assets.danfoss.com/approvals/196657/ID404448467481-0101.pdf) ID404448467481-0101 76 KB	(//ass
Functional Safety Certificate	Singapore	English	<b>TÜV 968 FSP 1217 03 20</b> (//assets.danfoss.com/approvals/220708/ID365930056154-0201.pdf) ID365930056154-0201 678 KB	(//ass
Functional Safety Certificate	Singapore	English	<b>TÜV 968_FSP_1217_04_22</b> (//assets.danfoss.com/approvals/220709/ID436042623261-0101.pdf) ID436042623261-0101 678 KB	(//ass
Manufacturer's Declaration	Singapore	English	<b>Danfoss MD 00723827 A1</b> (//assets.danfoss.com/approvals/158886/ID365946753660-0101.pdf) ID365946753660-0101 841 KB	(//ass
Manufacturer's Declaration	Singapore	English	<b>Danfoss MD 00729876 A4</b> (//assets.danfoss.com/approvals/158887/ID365946754661-0101.pdf) ID365946754661-0101 874 KB	(//ass
Manufacturer's Declaration	Singapore	English	<b>Danfoss MD 00732787 A1</b> (//assets.danfoss.com/approvals/158892/ID365946766670-0101.pdf) ID365946766670-0101 413 KB	(//ass

Visuals

Visuals	Document Category	Title	Download
	Product part or accessories photo	FC280_K1	› K1_NoBlind.jpg (//assets.danfoss.com/photos/262649/ID433732589640101.jpg)
	Dimensional drawing	MCAD MCC107 EMC filter K1T4 134B5463	› MCAD MCC107 EMC filter K1T4 134B5463.STP (//assets.danfoss.com/drawings/281191/ID3621474290101.stp)

Visuals	Document Category	Title	Download
	Circuit diagram	Wiring Schematic FC 280	<a href="#">› e30be202.pdf</a> <a href="https://assets.danfoss.com/drawings/278534/ID2643353670101.pdf">(/assets.danfoss.com/drawings/278534/ID2643353670101.pdf)</a>
No image available	Dimensional drawing	MCAD GLCP Adapter 132B0281	<a href="#">› MCAD GLCP Adapter 132B0281.stp</a> <a href="https://assets.danfoss.com/drawings/281208/ID3621474270101.stp">(/assets.danfoss.com/drawings/281208/ID3621474270101.stp)</a>
No image available	Eplan drawing	FC-280PK55T4E20H2BXCXXSXXXXAL	<a href="#">› FC-280PK55T4E20H2BXCXXSXXXXAL.zip</a> <a href="https://assets.danfoss.com/drawings/269745/ID3621484540101.zip">(/assets.danfoss.com/drawings/269745/ID3621484540101.zip)</a>
	Dimensional drawing	MCAD FC 280 K1 Installation	<a href="#">› FC280-K1-Installation.pdf</a> <a href="https://assets.danfoss.com/drawings/267575/ID3621477160101.pdf">(/assets.danfoss.com/drawings/267575/ID3621477160101.pdf)</a> <a href="#">› MCAD FC 280 K1 Installation.stp</a> <a href="https://assets.danfoss.com/drawings/267572/ID3621477160101.stp">(/assets.danfoss.com/drawings/267572/ID3621477160101.stp)</a> <a href="#">› fc280-k1-installation.dxf</a> <a href="https://assets.danfoss.com/drawings/267573/ID3621477160101.dxf">(/assets.danfoss.com/drawings/267573/ID3621477160101.dxf)</a>
	Dimensional drawing	MCAD VLT Blind Cover FC280 FC360	<a href="#">› MCAD VLT Blind Cover FC280_FC360.pdf</a> <a href="https://assets.danfoss.com/drawings/279468/ID3621475130101.pdf">(/assets.danfoss.com/drawings/279468/ID3621475130101.pdf)</a> <a href="#">› MCAD VLT Blind Cover FC280_FC360.stp</a> <a href="https://assets.danfoss.com/drawings/266603/ID3621475130101.stp">(/assets.danfoss.com/drawings/266603/ID3621475130101.stp)</a> <a href="#">› MCAD VLT Blind Cover FC280_FC360.dxf</a> <a href="https://assets.danfoss.com/drawings/269629/ID3621475130101.dxf">(/assets.danfoss.com/drawings/269629/ID3621475130101.dxf)</a>
	Dimensional drawing	MCAD Frame 1 adapter 132B0363	<a href="#">› MCAD Frame 1 adapter 132B0363.pdf</a> <a href="https://assets.danfoss.com/drawings/281167/ID3621474310101.pdf">(/assets.danfoss.com/drawings/281167/ID3621474310101.pdf)</a>
No image available	Eplan drawing	132B0254_Eplan	<a href="#">› 132B0254_Eplan.zip</a> <a href="https://assets.danfoss.com/drawings/437139/ID3621478710201.zip">(/assets.danfoss.com/drawings/437139/ID3621478710201.zip)</a>

Visuals	Document Category	Title	Download
	Dimensional drawing	MCAD VLT Control Panel LCP 21	› MCAD VLT Control Panel LCP 21.pdf (//assets.danfoss.com/drawings/269641/ID3621475130101.pdf)
			› MCAD VLT Control Panel LCP 21.stp (//assets.danfoss.com/drawings/269638/ID3621475130101.stp)
			› MCAD VLT Control Panel LCP 21.dxf (//assets.danfoss.com/drawings/279472/ID3621475130101.dxf)

Accessories

Search for specific accessories

Filter accessories

Show All

› Reset





(/sg/en/Drives  
/Low-Voltage-  
Drives/Access  
ories-for-Low-  
Voltage-  
Drives/Access  
ories-FC-  
280/LCP-  
Blind-  
cover%2C-  
IP20-  
21/p/132B026  
2)  
132B0262

## › LCP Blind cover, IP20/21

(/sg/en/Drives/Low-Voltage-Drives/Accessories-for-Low-Voltage-Drives/Accessories-FC-280/LCP-Blind-  
cover%2C-IP20-21/p/132B0262)

Use the blind cover to mount on a VLT® Midi Drive FC 280 when you does not need a control panel.

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Drives  
/Low-Voltage-  
Drives/Access  
ories-for-Low-  
Voltage-  
Drives/Access  
ories-FC-  
280/VLT%C2%  
AE-Control-  
Panel-LCP-  
21%C2-  
numeric/p/13  
2B0254)  
**132B0254**

## › **VLT® Control Panel LCP 21, numeric**

(/sg/en/Drives/Low-Voltage-Drives/Accessories-for-Low-Voltage-Drives/Accessories-FC-280/VLT%C2%AE-Control-Panel-LCP-21%C2-numeric/p/132B0254)

VLT® Control Panel LCP 21 Numerical

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Drives  
/Low-Voltage-  
Drives/Access  
ories-for-Low-  
Voltage-  
Drives/Access  
ories-FC-  
51/LCP-  
Remote-  
Mounting-  
Kit%2Cw-3m-  
cable/p/132B  
0102)

**132B0102**

## › LCP Remote Mounting Kit,w/ 3m cable

(/sg/en/Drives/Low-Voltage-Drives/Accessories-for-Low-Voltage-Drives/Accessories-FC-51/LCP-Remote-Mounting-Kit%2Cw-3m-cable/p/132B0102)

Remote installation kit for VLT Micro Drive FC 51 for installing an LCP  
11 or LCP

12 control unit in a control cabinet door or similar. (can also be  
retrofitted).

Contains fastening elements, seal and 3 m connection cable with plugs.

LCP is not included in the scope of delivery.

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Drives  
/Low-Voltage-  
Drives/Access  
ories-for-Low-  
Voltage-  
Drives/Access  
ories-FC-  
280/VLT%C2%  
AE-24-V-DC-  
Supply-MCB-  
106/p/132B03  
68)  
**132B0368**

## › VLT® 24 V DC Supply MCB 106

(/sg/en/Drives/Low-Voltage-Drives/Accessories-for-Low-Voltage-Drives/Accessories-FC-280/VLT%C2%AE-24-V-DC-Supply-MCB-106/p/132B0368)

VLT® 24 V DC Supply MCB 106 for FC-280

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Drives  
/Low-Voltage-  
Drives/Access  
ories-for-Low-  
Voltage-  
Drives/Access  
ories-FC-  
280/Adapter-  
Plate%2C-  
VLT2800-size-  
B/p/132B0364  
)

132B0364

## › Adapter Plate, VLT2800 size B

(/sg/en/Drives/Low-Voltage-Drives/Accessories-for-Low-Voltage-Drives/Accessories-FC-280/Adapter-Plate%2C-VLT2800-size-B/p/132B0364)

Adapter plate, VLT2800 size B VLT 2822 200-240 volts

VLT 2822-2840 380-480 volts

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Drives  
/Low-Voltage-  
Drives/Access  
ories-for-Low-  
Voltage-  
Drives/Access  
ories-FC-  
280/Adapter-  
Plate%2C-  
VLT2800-size-  
A/p/132B0363  
)

132B0363

## › Adapter Plate, VLT2800 size A

(/sg/en/Drives/Low-Voltage-Drives/Accessories-for-Low-Voltage-Drives/Accessories-FC-280/Adapter-  
Plate%2C-VLT2800-size-A/p/132B0363)

Adapter Plate, VLT2800 size A  
VLT 2803-2815 200-240 Volt  
VLT 2805-2815 380-480 Volt

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Drives  
/Low-Voltage-  
Drives/Access  
ories-for-Low-  
Voltage-  
Drives/Access  
ories-FC-  
280/Adaptor  
%2C-  
Graphical-  
LCP/p/132B02  
81)  
**132B0281**

## › Adaptor, Graphical LCP


(/sg/en/Drives/Low-Voltage-Drives/Accessories-for-Low-Voltage-Drives/Accessories-FC-280/Adaptor%2C-  
Graphical-LCP/p/132B0281)

Graphic LCP adapter for LCP102

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Drives  
/Low-Voltage-  
Drives/Access  
ories-for-Low-  
Voltage-  
Drives/Access  
ories-FC-  
280/IP21-  
Type-1-  
conversion-  
kit%2C-  
K1/p/132B033  
5)

132B0335

## › IP21 / Type 1 conversion kit, K1

(/sg/en/Drives/Low-Voltage-Drives/Accessories-for-Low-Voltage-Drives/Accessories-FC-280/IP21-Type-1-  
conversion-kit%2C-K1/p/132B0335)

IP21 / Type 1 conversion kit, K1

Where to buy

+ Add to comparison list

+Add to My Product List





(/sg/en/Accessories-FCM-106/VLT%C2%AE-Memory-Module-Programmer-MCM-101/p/134B0792)  
134B0792

› **VLT® Memory Module Programmer MCM 101**  
(/sg/en/Accessories-FCM-106/VLT%C2%AE-Memory-Module-Programmer-MCM-101/p/134B0792)

Where to buy

- + Add to comparison list
- +Add to My Product List

Spare Parts

Search for specific spare parts

Select Refinements

DrivePro Category

Spare Part Category

-

› Reset all refiners



(/sg/en/Bus-cable-decoupling-kit%2C-FC-280/p/132B0369)  
132B0369

## › Bus cable decoupling kit, FC-280

(/sg/en/Bus-cable-decoupling-kit%2C-FC-280/p/132B0369)

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Terminal-Cover-frame-size-K1/p/132B0354)  
132B0354

## › Terminal Cover frame size K1

(/sg/en/Terminal-Cover-frame-size-K1/p/132B0354)

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Access  
ory-bag-FC-  
280-  
plugs/p/132B  
0350)  
**132B0350**

## › **Accessory bag FC-280 plugs**

(/sg/en/Accessory-bag-FC-280-plugs/p/132B0350)

Accessory bag FC-280 plugs

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/VLT%  
C2%AE-  
Cassette-  
control---  
ProfiNet/p/13  
2B0348)  
**132B0348**

## › **VLT® Cassette control - ProfiNet**

(/sg/en/VLT%C2%AE-Cassette-control---ProfiNet/p/132B0348)

VLT® Cassette control - ProfiNet

Where to buy

+ Add to comparison list

+Add to My Product List

---



(/sg/en/Drives  
/DrivePro%C2  
%AE-  
Services/Exch  
ange-  
Units/FC-  
280P1K1T4E2  
0H2BXCXXS  
XXXXAL/p/13  
4U7771)  
**134U7771**

› **FC-280P1K1T4E20H2BXCXXSXXXXAL**

(/sg/en/Drives/DrivePro%C2%AE-Services/Exchange-Units/FC-  
280P1K1T4E20H2BXCXXSXXXXAL/p/134U7771)

FC-280P1K1T4E20H2BXCXXSXXXXAL

Frequency converter  
FC-280P1K1T4E20H2BXCXXSXXXXAL  
VLT® Midi Drive FC-280  
1.1 kW / 1.5 HP, Three phase 380-480 VAC  
IP20 / Chassis, EMC Cat C3 (200/400V)  
Brake chopper, No display  
Coated PCB, Latest release  
Integrated PROFINET  
Frame: K1  
Other options according to Model code

**Model code:** FC-280P1K1T4E20H2BXCXXSXXXXAL

Note: The FC 280 does not include an LCP display or Memory Module.  
The LCP and the Memory Module can be ordered as an Accessory.

Where to buy

Re-configure (/sg/en/134U7771/configuratorPage/CPQCONFIGURATOR)

+ Add to comparison list  
+Add to My Product List



(/sg/en/Drives  
/DrivePro%C2  
%AE-  
Services/Exte  
nded-  
Warranty/Driv  
ePro-ExWarr-  
Work-Shop-  
PG01-36-  
Month/p/130  
R1102)  
130R1102

## › DrivePro ExWarr Work Shop PG01 36 Month

(/sg/en/Drives/DrivePro%C2%AE-Services/Extended-Warranty/DrivePro-ExWarr-Work-Shop-PG01-36-Month/p/130R1102)

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drivesworkshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales officefor extended warranty contract options

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Drives  
/DrivePro%C2  
%AE-  
Services/Exte  
nded-  
Warranty/Driv  
ePro-ExWarr-  
Work-Shop-  
PG01-48-  
Month/p/130  
R1104)  
130R1104

## › DrivePro ExWarr Work Shop PG01 48 Month

(/sg/en/Drives/DrivePro%C2%AE-Services/Extended-Warranty/DrivePro-ExWarr-Work-Shop-PG01-48-Month/p/130R1104)

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Drives  
/DrivePro%C2  
%AE-  
Services/Exte  
nded-  
Warranty/Driv  
ePro-ExWarr-  
Work-Shop-  
PG01-42-  
Month/p/130  
R1103)  
130R1103

## › DrivePro ExWarr Work Shop PG01 42 Month

(/sg/en/Drives/DrivePro%C2%AE-Services/Extended-Warranty/DrivePro-ExWarr-Work-Shop-PG01-42-Month/p/130R1103)

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Drives  
/DrivePro%C2  
%AE-  
Services/Exte  
nded-  
Warranty/Driv  
ePro-ExWarr-  
Work-Shop-  
PG01-54-  
Month/p/130  
R1105)  
130R1105

## › DrivePro ExWarr Work Shop PG01 54 Month

(/sg/en/Drives/DrivePro%C2%AE-Services/Extended-Warranty/DrivePro-ExWarr-Work-Shop-PG01-54-Month/p/130R1105)

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

Where to buy

+ Add to comparison list

+Add to My Product List





(/sg/en/Drives  
/DrivePro%C2  
%AE-  
Services/Exte  
nded-  
Warranty/Driv  
ePro-ExWarr-  
Work-Shop-  
PG01-66-  
Month/p/130  
R1107)  
130R1107

## › DrivePro ExWarr Work Shop PG01 66 Month

(/sg/en/Drives/DrivePro%C2%AE-Services/Extended-Warranty/DrivePro-ExWarr-Work-Shop-PG01-66-Month/p/130R1107)

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Drives  
/DrivePro%C2  
%AE-  
Services/Exte  
nded-  
Warranty/Driv  
ePro-ExWarr-  
Work-Shop-  
PG01-60-  
Month/p/130  
R1106)  
130R1106

## › DrivePro ExWarr Work Shop PG01 60 Month

(/sg/en/Drives/DrivePro%C2%AE-Services/Extended-Warranty/DrivePro-ExWarr-Work-Shop-PG01-60-Month/p/130R1106)

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Drives  
/DrivePro%C2  
%AE-  
Services/Exte  
nded-  
Warranty/Driv  
ePro-ExWarr-  
Work-Shop-  
PG01-72-  
Month/p/130  
R1108)  
130R1108

## › DrivePro ExWarr Work Shop PG01 72 Month

(/sg/en/Drives/DrivePro%C2%AE-Services/Extended-Warranty/DrivePro-ExWarr-Work-Shop-PG01-72-Month/p/130R1108)

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Drives  
/DrivePro%C2  
%AE-  
Services/Exte  
nded-  
Warranty/Driv  
ePro-ExWarr-  
Work-Shop-  
PG01-30-  
Month/p/130  
R1101)  
130R1101

## › DrivePro ExWarr Work Shop PG01 30 Month

(/sg/en/Drives/DrivePro%C2%AE-Services/Extended-Warranty/DrivePro-ExWarr-Work-Shop-PG01-30-Month/p/130R1101)

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drivesworkshop, or shipment of a replacement product to the site. You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales officefor extended warranty contract options

Where to buy

+ Add to comparison list

+Add to My Product List



(/sg/en/Drives  
/DrivePro%C2%  
%AE-  
Services/Exte  
nded-  
Warranty/Driv  
ePro-ExWarr-  
Onsite-PG01-  
48-  
Months/p/130  
R1004)  
130R1004

**› DrivePro ExWarr Onsite PG01 48 Months**  
(/sg/en/Drives/DrivePro%C2%AE-Services/Extended-Warranty/DrivePro-ExWarr-Onsite-PG01-48-Months/p/130R1004)

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.  
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

Where to buy

- + Add to comparison list
- +Add to My Product List

View: 10 (/sg/en/referenceSearch?page=0&pageSize=10) | 25 (/sg/en/referenceSearch?page=0&pageSize=25)  
⏪ (/sg/en/referenceSearch?page=0&pageSize=10) 1 / 2 ⏩ (/sg/en/referenceSearch?page=1&pageSize=10)

Software

Software and firmware to support existing functionality

Software Type	Title	Version	Released	
System software	VLT® Midi Drive FC 280 Ethernet/IP EDS (//assets.danfoss.com/software/283923/ID458721760898-0101.zip) 5 KB	1.20	09/12/2016	(//assets.

	Title	Version		
System software	<b>VLT® Midi Drive FC 280 CANOpen EDS</b> <a href="https://assets.danfoss.com/software/285985/ID461024314934-0101.zip">(/assets.danfoss.com/software/285985/ID461024314934-0101.zip)</a> 15 KB	1.20	09/12/2016	<a href="#">(/assets.</a>
System software	<b>VLT® Midi Drive FC 280 PROFIBUS GSD</b> <a href="https://assets.danfoss.com/software/285987/ID461024898935-0101.zip">(/assets.danfoss.com/software/285987/ID461024898935-0101.zip)</a> 4 KB	1.0	10/10/2016	<a href="#">(/assets.</a>
System software	<b>VLT® Midi Drive Support File</b> <a href="https://assets.danfoss.com/software/286113/ID461031958951-0901.zip">(/assets.danfoss.com/software/286113/ID461031958951-0901.zip)</a> 287 KB	2.00 (latest)	02/03/2022	<a href="#">(/assets.</a>
System software	<b>VLT® Drives EtherNet/IP EDS</b> <a href="https://assets.danfoss.com/software/297265/ID461838311590-0201.zip">(/assets.danfoss.com/software/297265/ID461838311590-0201.zip)</a> 59 KB	02	27/06/2016	<a href="#">(/assets.</a>
System software	<b>VLT® Midi Drive FC 280 PROFINET GSDML</b> <a href="https://assets.danfoss.com/software/311710/ID462345552876-0101.zip">(/assets.danfoss.com/software/311710/ID462345552876-0101.zip)</a> 14 KB	01	30/10/2020	<a href="#">(/assets.</a>
Software tools	<b>VLT® Motion Control Tool MCT31</b> <a href="https://assets.danfoss.com/software/317123/ID463107821219-0101.zip">(/assets.danfoss.com/software/317123/ID463107821219-0101.zip)</a> 25754 KB	2.0.4	17/10/2017	<a href="#">(/assets.</a>
System software	<b>VLT® EtherNet/IP Add-on Instructions</b> <a href="https://assets.danfoss.com/software/317194/ID463138688276-0101.zip">(/assets.danfoss.com/software/317194/ID463138688276-0101.zip)</a> 442 KB	01	27/09/2013	<a href="#">(/assets.</a>
System software	<b>VLT® Midi Drive FC 280 POWERLINK XDD</b> <a href="https://assets.danfoss.com/software/317288/ID463166045365-0101.zip">(/assets.danfoss.com/software/317288/ID463166045365-0101.zip)</a> 15 KB	01	09/12/2016	<a href="#">(/assets.</a>
System software	<b>VLT® MCA101 PROFIBUS GSD</b> <a href="https://assets.danfoss.com/software/317290/ID463167260367-0101.zip">(/assets.danfoss.com/software/317290/ID463167260367-0101.zip)</a> 76 KB	01	03/11/2010	<a href="#">(/assets.</a>

View:

[10 \(/sg/en/setSoftwarePage?productCode=134U7769&page=0&pageSize=10\)](#)

[25 \(/sg/en/setSoftwarePage?productCode=134U7769&page=0&pageSize=25\)](#)

[FAQs \(/sg/en/faq\)](/sg/en/faq)

[About us  
\(https://www.danfoss.com/en-sg/about-danfoss/\)](https://www.danfoss.com/en-sg/about-danfoss/)

[Find nearest distributor  
\(/sg/en/find-a-distributor\)](/sg/en/find-a-distributor)

[Contact us  
\(https://www.danfoss.com/en-sg/contact-us/\)](https://www.danfoss.com/en-sg/contact-us/)

[Terms of use  
\(https://www.danfoss.com/en/terms/\)](https://www.danfoss.com/en/terms/)

[Terms of use  
\(https://www.danfoss.com/en-sg/terms/\)](https://www.danfoss.com/en-sg/terms/)

[Privacy policy \(/sg/en/privacy\)](/sg/en/privacy)

[General information  
\(https://www.danfoss.com/en/terms/generalinformation/\)](https://www.danfoss.com/en/terms/generalinformation/)

[General information  
\(https://www.danfoss.com/en-sg/terms/generalinformation/\)](https://www.danfoss.com/en-sg/terms/generalinformation/)

[Cookies](#)

[Configuration disclaimer \(/sg/en/disclaimer\\_cpq\)](/sg/en/disclaimer_cpq)